

# SONY®

Silicone Case &  
Screen Protection Sheet  
CKM-NWA50



\* 4 7 4 0 8 5 7 0 1 \* (1)

4-740-857-01(1)

©2018 Sony Corporation Printed in Malaysia

## 使いかた / How to use / 如何使用



### 日本語

#### ご注意

- ウォークマン®がケースにしっかり確実に取り付けられているかを確認してください。
- 不要となった剥離シートは、小さなお子さまが誤って飲みこんでしまうおそれがありますので、ご注意ください。
- 取り付けや取り外しの際、ケースに強い力を加えないようにしてください。変形、破損の原因となります。
- ヘッドホンコードをケースに巻き付けて使用しないでください。変形、破損の原因となります。
- 市販のベンジン、アルコールなどの溶剤は、変色、劣化の原因となりますので使用しないでください。

本文に記載するシステム名、製品名は、一般に各開発メーカーの登録商標あるいは商標です。

For Japan Only  
**使い方相談窓口**

フリーダイヤル・・・・・・・・・・ 0120-333-020  
携帯電話・PHS・一部のIP電話・・ 050-3754-9577  
FAX・・・・・・・・・・・・・・・・・・ 0120-333-389

**English**

**Note**

- Be sure that the Walkman® is attached to the case correctly and securely.
- Take care when disposing the removed peeling sheet in order to prevent children from accidentally swallowing the sheet.
- Avoid applying strong pressure when attaching or removing the case. Doing so may cause the case to deform or break.
- Refrain from wrapping the headphone cable around the case during use. Doing so may cause the case to deform or break.
- Refrain from using commercially available solvents such as benzene or alcohol as doing so may cause discoloration or deterioration of the case.

The names of systems and/or products that appear in this document are generally trademarks or registered trademarks of their respective developers and manufacturers.

**繁體中文**

**規格**

尺寸 (寬/高/深) : 約 58 mm × 100 mm × 13 mm

質量 : 約 12 g