



SRS-XB21



4-734-036-12(1)

©2018 Sony Corporation Printed in China




* 4 7 3 4 0 3 6 1 2 * (1)



1



2



3



Reference Guide



Android / iPhone




<http://www.sony.net/smcpp/>




Sony Music Center




LIGHT







ON






OFF






Wireless Party Chain



Speaker Add



Android



Speaker Add
Wireless Party Chain
Party Booster



http://rd1.sony.net/help/speaker/srs-xb21/h_zz/